EN Combination lock for the golf travel cover – instructions

The lock at a glance

The lock opens with a four-digit number code; it has no key. The factory code is **0000**; we recommend changing it to your own code straight away.

- **Shackle** – the metal loop at the top; it goes through the holes in the zip pulls.
- **Four number dials** on the side – each one sets one digit of the code (0–9).
- **Read the code** in the middle row of digits, the one facing you; from top to bottom are digits 1 to 4.

Opening and locking

Opening

1. Turn the dials so that your code shows in the middle row (factory code 0000).
2. Pull the shackle up.

Locking

1. Push the shackle back into the lock body until it clicks.
2. Turn the dials to other numbers so the code can't be seen.
3. Pull on the shackle – the lock must stay closed.

Setting your own code

The code can only be changed while the lock is open, and it takes about a minute. Set it before you attach the lock to the cover.

1. Open the lock with the current code (factory code 0000) and pull the shackle up.
2. Turn the shackle 90° anticlockwise and press it down.
3. Hold the shackle down and set the new code on the dials.
4. Release the shackle and turn it back to its original position. The new code is now saved.
5. Test it: close the lock, scramble the dials, set the new code and open the lock.

Write the new code down somewhere other than your luggage, for example on your phone.

Combination lock for the golf travel cover – instructions

Using it on the travel cover

1. Close the main zip so that both zip pulls meet.
2. Thread the shackle through the holes in both zip pulls.
3. Close the lock and scramble the dials.

The lock prevents accidental opening and deters quick theft, but it is not a safe. Do not carry documents, electronics or money in the travel cover.

Flights to the USA: airport security may cut off a lock without the TSA logo (red diamond) when inspecting your bag. For these flights, lock the cover with a TSA lock, or leave it unlocked and pack the lock inside.

If the lock won't open

- **The code is set but the shackle won't come out:** check that each digit sits exactly in line, not halfway between two positions. Turn the dials back and forth, set the code again and pull the shackle.
- **Forgotten code:** first try the factory code 0000 – it may never have been changed. Otherwise the lock cannot be opened without the code and the code cannot be recovered; the lock has to be cut carefully with bolt cutters so that the zips are not damaged.

Care and tips

- Don't use your date of birth or simple sequences (1234, 0000) as your code.
- Always scramble the dials after locking.
- Keep the lock away from sand and mud. If it gets dirty, rinse it with water and let it dry.
- If the dials are stiff, spray a little silicone spray into the gaps. Don't use oil – it attracts dust.